

DESCRIPTION

The Ask-4® Kit #101 is a single zone audio monitoring system. It is designed for audio monitoring and interfacing with DVR's, VCR's or other audio devices that accept line level input. The microphone can be ceiling or wall mounted and provides a 30' diameter circle coverage. The desktop audio base station (APR-1) contains a 3" speaker for monitoring live audio and playback from a DVR and VCR. Microphone is pre-amplified and produces line level output.

KIT CONTENT

- 1 Verifact™ "A" Microphones
- 1 Model APR-1 Audio Base Station
- 1 AD-1 12Vdc power supply
- 1 Dual RCA cables for connection to VCR/DVR

NOTE: APR-1 Base Station can be equipped for 10" rack mounting. Request RM-1935 Rack Mount Assembly.

APPLICATION

The ASK-4® Kit#101 is designed for numerous applications such as:

- Convenience Stores
- Fast Food Restaurants
- Interrogation Rooms
- Child Abuse Interviews
- Sleep Disorder Centers
- Speech Therapy Labs
- Cashier Booths
- Detention Centers
- Medical Treatment Rooms
- Car Dealership Sales Contact Rooms
- Casino use in:
 - Softcount Room
 - Cash Cages

WIRING REQUIREMENTS

2 Conductor shielded cable, 22 gauge with a 24 gauge drain wire.
 NOTE: Unshielded cable is not satisfactory for audio systems


IMPORTANT NOTICE

When this equipment is used as part of an audio monitoring system, the law requires that the public be given notice of AUDIO MONITORING ON THE PREMISES. A decal notice is included with each microphone shipped.


FEDERAL LAW REFERENCES:

Federal Regulations, US Code, Title 18. Crime and Criminal Procedure, Sec 2510.

**MANUFACTURED
 IN THE**



Verifact "A" Microphone



APR-1



AD-1

FEATURES

- Audio output (RCA) to DVR, VCR
- 3.5 mm headphone jack for private listening
- Omni-directional microphone can pick up normal sounds 15' away if wall mounted, or within a 30' diameter circle if ceiling mounted
- Microphone may be mounted up to 1000' from the APR-1 Base Station
- 3" speaker for monitoring live audio and playback from a DVR or VCR

SPECIFICATIONS (Microphone - Verifact "A")

■ Type	Electret Condenser
■ Output	Line Level (0dB @1KΩ), unbalanced
■ Frequency response	40 Hz to 15 kHz ± 1 dB
■ Current drain	4 mA
■ Supply voltage	12Vdc, 500mA
■ Dimensions	4" Dia x 1 1/2" H
■ Weight (shipping)	3.0 Lbs (1.4 Kg)

SPECIFICATIONS (Base Station - APR-1)

■ Input sensitivity (mic)	0.78V
■ Monitor output power	1W @8Ω
■ Audio line output impedance	600Ω or higher
■ Audio input impedance	10KΩ
■ Freq. response	100 Hz to 10kHz
■ Headphone impedance	8 to 600Ω
■ Power supply	12 Vdc, 500 mA
Dimensions	8 1/4"L x 5 3/4"W x 1 3/8" H
Weight	4 lbs. (1.8)Kg

WARRANTY

LOUROE ELECTRONICS® warrants that at the time of shipment products manufactured by LOUROE ELECTRONICS to be free of defects in material and workmanship. Should a defect appear within one year (12 months) from date of shipment, LOUROE ELECTRONICS will, at its sole discretion, repair or replace the defective equipment. This equipment shall not be accepted for repair or return without prior notification by LOUROE ELECTRONICS.

This warranty does not extend to any Louroe product that has been subjected to improper or incorrect installation, misuse, accident, or in violation of installation instructions provided by LOUROE ELECTRONICS.

Returned shipments to LOUROE ELECTRONICS shall be at customer's expense. LOUROE ELECTRONICS will return the equipment prepaid via best way.